

FINISHED WALL SPECS

FOR GRAPHIC APPLICATION

MAC GRAPHIC SERVICES

PREPARATION

Wall(s) should be primed first then painted with two coats of semi-gloss or eggshell finish latex paint with a light sanding in between coats.

It is recommended that the paint dry/cure/outgas for at least five days before application of any graphic materials. The finished wall should be very smooth [level 4 or 5 if achievable] prior to application of graphics.

PLEASE NOTE

If using low VOC paints on projects, please contact Tim at **732.453.4251** to discuss. It is recommended that you do not use low VOC paints on walls that will receive adhesive graphics.

CONTACT US

If you are having any trouble, please ask us for any help or information. We are here to make your job easier!

OFFICE PHONE: +1.732.663.0111

EMAIL: SALES@MACGRAPHICSERVICES.COM